

Removable Locking Bollard Installation Instructions (Pre-Concrete)



Step #1
Auger or dig out 10-12" hole to
depth of core (generally 18")



Step #2
Level plum and concrete around
receiving steel floor sleeve



Step #3
After concrete cures, make
sure the floor sleeve is secure
before dropping in Removable
Locking Bollard