

Removable Locking Bollard Installation Instructions

(Core Drill)

Tools Required: Jack Hammer, Shovel, Post Hole Digger, Wheel Barrel, Water, Cement



Step #1

Core, cut or dig approximately 10" round hole, 22" deep through existing surface



Step #2

Insert steel floor sleeve into hole, center and level as needed



Step #3

Pour concrete level with top of steel floor sleeve



Step #4

After concrete cures, drop in Removable Locking Bollard