

Setup Instructions

1. Unpack and Unroll

Remove the sign from its box and fully unroll it.

2. Position the Braces

Rotate the cross braces so they form an “X.”

3. Secure the Braces

Bend the braces and insert their ends into the plastic corner pockets.

4. Prepare the Battery Box

Unscrew the battery box lid, insert eight (8) C-cell alkaline batteries, and close the lid securely.

5. Connect Power

Plug the wire from the back of the sign into the wire from the battery box.

6. Mount the Battery Box

Use the velcro strap to attach the battery box to the back spine of the sign or directly onto the stand.

7. Power On

Flip the On/Off switch on the battery box to activate the flashing LEDs.

Please Note: Batteries are not included with purchase.

