

BOLLARD COVER SIZING TOOL



Place paper horizontally over pipe from **OD to OD, to get a correct measurement.

****OD = Outside Diameter**

***IS = Ideal Sleeve**, IS sizes are specific to Ideal Shield brand covers

PRINT INSTRUCTIONS: Print to 'Actual Size', **DO NOT CHOOSE 'Fit to Page'**

12 3/4" OD = 12" IS*



EXAMPLE: 3 1/2" OD = 3" IS*

MEASURING PIPE W/ CONCRETE DOME

How to determine which sleeve size to order:

1. Measure the circumference (distance around the post)
2. Take that dimension and divide by pi (3.14)

Example: Circumference is 21"
 Divide by 3.14
 Pipe Size is 6.625"

3. Find your pipe size in the chart below and see what Ideal Sleeve Size matches your Pipe OD (pipe size)

Example cont'd: If your Pipe Size is 6.625", the Ideal Sleeve Size you will need is 6"

SIZE CHART

Pipe OD	Ideal Sleeve Size	Sleeve ID	Pipe Circumference	Pipe Size
3 1/2"	3"	3 5/8"	11"	3"
4"	3 1/2"	4 1/8"	12 1/2"	3 1/2"
4 1/2"	4"	5"	14"-15"	4"
5 1/2"	5 1/2"	6"	17 1/2"	5"
6 5/8"	6"	7"	20 1/2"-21 1/2"	6"
7 1/2"	7 1/2"	8"	24"	7"
8 5/8"	8"	9"	27"-27 1/2"	8"
10 3/4"	10"	11"	34"-34 1/2"	10"
12 3/4"	12"	13"	37 5/8"	12"

PART NUMBER EXAMPLE

BPD-YL-04-060-S

PRODUCT CODE
WALL THICKNESS

COLOR
CODE

DIAMETER
(INCHES)

HEIGHT
(INCHES)

SLEEVE